



- NOTES:
1. REFER TO FIRESTONE WEBSITE FOR MOST CURRENT INFORMATION.
 2. NAILING AND METAL COUNTERFLASHING ARE NOT REQUIRED IF MEMBRANE IS RUN UP AND OVER CURB WALLS PRIOR TO INSTALLATION OF R.T.U.
 3. BONDING ADHESIVE REQUIRED BETWEEN MEMBRANE AND INSULATION FOR FULLY ADHERED SYSTEMS.
 4. WHEN REINFORCEMENT OF TPO MEMBRANE IS EXPOSED, REFER TO UT-LS-14 FOR CUT EDGE EXPOSED, REFER TO UT-LS-14 FOR CUT EDGE
 5. INSTALL METAL WORK IN ACCORDANCE WITH CURRENT SMACNA RECOMMENDATIONS.
 6. WOOD BLOCKING CAN BE USED BELOW CURB FLANGE (TO MATCH INSULATION THICKNESS) CAN BE SUBSTITUTED FOR STRUCTURAL CURB ATTACHMENT
 7. APPROVED WOODEN CURBS CAN BE USED IN PLACE OF METAL CURBS
 8. REFER TO STANDARD FIRESTONE DETAILS FOR CORNER FLASHING

	FLASHING DETAIL at INSULATED CURB W/COUNTER FLASHING (UNIT FLANGE MOUNTED TO SUBSTRATE)		MAXIMUM WARRANTY: 20 YEARS	
	SUNWAVE™ PRISMATIC SKYLIGHTS		ACCEPTABLE SYSTEMS: MOD BITUMEN	
Firestone Building Products Sales: (800- 428-4442 Technical (800) 428-4511 www.firestonebpco.com			ISSUE / REVISION DATE: 11/02/2017	DETAIL NO. FS-DL-12
			NOT TO SCALE	