



**NOTES:**

1. IF SEAMS RUN WITHIN 18" (457.2 mm) OF DRAIN, INSTALL A 4' (1.2 M) X 4' (1.2 M) MIN. EPDM PATCH ON TOP OF MEMBRANE ASSURING SEAM IS COVERED. AS AN ALTERNATE, FLASH THE SEAM WITH QUICKSEAM FORMFLASH EXTENDING 3" (76.2 mm) MIN. ON TO HORIZONTAL SUBSTRATE.
2. IN RENOVATION APPLICATIONS:
  - A. REMOVE EXISTING FLASHINGS DOWN TO METAL SUMP.
  - B. REPAIR OR REPLACE BROKEN CLAMPING RING.
  - C. DRILL AND TAP BROKEN DRAIN BOLTS AND REPLACE.

**MAXIMUM WARRANTY: N/A**

**DRAIN**

GEOGARD™

ACCEPTABLE SYSTEMS:  
EPDM, EPDM-R, ECOWHITE EPDM

ISSUE / REVISION  
DATE:

7-28-2015

DETAIL NO.

D-1



Lining In Action™