



1. CLEAN ALL FIRESTONE GEOGARD SURFACES AS REQUIRED BY FIRESTONE SPECIFICATIONS.
2. TAKE EXTRA CARE TO CLEAN FACTORY SPLICES AND OTHER AREAS WHERE EXCESS DUSTING AGENT MAY HAVE ACCUMULATED.
3. ADDITIONAL SEAMING REQUIREMENTS ARE NECESSARY WHEN .090 MIL (2.25 MM) GEOMEMBRANE IS USED. CONTACT FIRESTONE SPECIALTY PRODUCTS DEPARTMENT.

MAXIMUM WARRANTY: **N/A**

DETAIL NO. **S-2**

3" Inseam Splice Tape Seam



GEOGARD™

ACCEPTABLE SYSTEMS:
EPDM, EPDM-R, ECOWHITE EPDM

ISSUE / REVISION
DATE:
7-30-2015

NOT TO SCALE