



NOTES:

1. IF SEAMS RUN WITHIN 18" (457.2 MM) OF DRAIN, INSTALL A 4' (1.2 M) X 4' (1.2 M) MIN. PPR-R PATCH ON TOP OF GEOMEMBRANE ASSURING SEAM IS COVERED. AS AN ALTERNATE, COVER THE SEAM WITH UNSUPPORTED PPR GEOMEMBRANE EXTENDING 3" (76.2 MM) MIN. ON TO HORIZONTAL SUBSTRATE.
2. IN RENOVATION APPLICATIONS:
 - A. REMOVE EXISTING MATERIAL DOWN TO METAL SUMP.
 - B. REPAIR OR REPLACE BROKEN CLAMPING RING.
 - C. DRILL AND TAP BROKEN DRAIN BOLTS AND REPLACE.

Firestone
20 Geomembranes that Work 09

PP-R Geomembrane
Drain

Detail No. ML-D-1
Systems Polypropylene