



- NOTES:**
- 1. CONCRETE SURFACES AT ATTACHMENTS TO BE SMOOTH BEFORE INSTALLATION**
 - 2. REFER TO ML-T-7 FOR HIGH WALL FLASHINGS.**
 - 3. GEOMEMBRANE AND LINER ARE INTERCHANGEABLE TERMS.**

<h1 style="margin: 0;">Firestone</h1> <p style="margin: 0; font-size: small;">20 Geomembranes that Work 09</p>	<h2 style="margin: 0;">FP-R Geomembrane</h2> <p style="margin: 0; font-size: x-small;">Vertical Mechanical Attachment Below the Water Line</p>	<h2 style="margin: 0;">Detail No. ML-T-9</h2> <p style="margin: 0; font-size: x-small;">Systems Polypropylene</p>
--	--	---