

## RubberGard™ EcoWhite™ EPDM QuickSeam™ SA Pipe Boot Patch

Item Description  
Pipe Boot

Item Number  
W56RAC160J



### Product Information

#### Description:

RubberGard EcoWhite EPDM QuickSeam SA Pipe Boot Patch ("EW QS SA Pipe Boot Patch") consists of 18" X 18" EcoWhite membrane fully and completely factory laminated to EcoWhite seam tape with a 7¼" diameter hole die-cut in the center. It can be used to flash the flange of QuickSeam Pipe Boots in conjunction with EcoWhite roofing systems where allowed by Firestone specifications.

EcoWhite tape is used as the tape adhesive to field splice EW QS SA Pipe Boot Patch to primed flanges of QuickSeam Pipe Boot and EcoWhite membrane. The polymeric release liner (protects the tape until field application) is perforated to allow removal of the liner in separate sections.

#### Method of Application:

1. Prime all surfaces (membrane and flanges) to receive EW QS SA Pipe Boot Patch using Single-Ply QuickPrime™ Primer or Single-Ply LVOC Primer scrub applied with QuickScrubber™ Pad and Handle.
2. Allow primer to flash off. Use Touch-Push test to verify primer readiness.
3. Remove release liner in sections to mate EW QS SA Pipe Boot Patch to primed substrates only when EW QS SA Pipe Boot Patch is properly positioned over primed substrate.
4. Roll the freshly mated EW QS SA Pipe Boot Patch with silicone coated rubber hand roller to ensure proper mating.
5. Apply seam edge treatment at all lap edges of the EW QS SA Pipe Boot Patch: the perimeter and the die-cut center hole.

#### Storage:

- Store in original unopened containers indoors at temperatures between 60 °F (15.6 °C) and 80 °F (26.7 °C).
- Do not store on roof in direct sunlight or at temperatures above 80 °F (26.6 °C).
- When exposed to lower temperatures; restore to room temperature prior to use.
- Shelf life of two years can be expected when stored in original container at temperatures between 60 °F (15.6 °C) and 80 °F (26.7 °C).
- Shelf life will be shortened if exposed to elevated temperatures.

#### LEED® Information:

Post Consumer Recycled Content: 0%  
Post Industrial Recycled Content: 0%  
Manufacturing Location: Michigan Center, MI

\*NOTE: LEED® is a registered trademark of the U.S. Green Building Council.

## RubberGard™ EcoWhite™ EPDM QuickSeam™ SA Pipe Boot Patch

### Precautions:

Refer to Safety Data Sheets (SDS).

### Typical Properties

Property	Value
<b>QUICKSEAM TAPE</b>	
Base:	Rubber Polymers
Color:	White
Solvents:	None
Solids:	100%
Cured State:	Cured
Thickness:	0.020"(0.508 mm) ±0.005"(0.127 mm)
Dimensions:	18" X 18" (457.2 mm X 457.2 mm) with 7¼" (184.1 mm) diameter center hole
<b>MEMBRANE</b>	
Base:	Rubber Polymers
Color:	White
Solvents:	None
Cured State:	Cured
Thickness:	0.020"(0.508 mm) ± 0.005" (0.127 mm)
Dimensions:	18" X 18" (457.2 mm X 457.2 mm) with 7¼" (184.1 mm) diameter center hole

### Packaging:

- 25 Pieces per carton
- 24 Cartons per pallet

Please contact Quality Building Services Technical Department at 1-800-428-4511 for further information.

*This sheet is meant to highlight Firestone products and specifications and is subject to change without notice. Firestone takes responsibility for furnishing quality materials which meet published Firestone product specifications or other technical documents, subject to normal roof manufacturing tolerances. Neither Firestone nor its representatives practice architecture. Firestone offers no opinion on and expressly disclaims any responsibility for the soundness of any structure. Firestone accepts no liability for structural failure or resultant damages. Consult a competent structural engineer prior to installation if the structural soundness or structural ability to properly support a planned installation is in question. No Firestone representative is authorized to vary this disclaimer.*