

Firestone EPDM Geomembrane Installation Detail 5

Using Sod Staples to Hold Geotextile Against Wind Uplift



Step 1- Use sod staples to hold the geotextile in place.



Step 2- Remove all bent or excess staples that pose a hazard of puncturing the Firestone EPDM Geomembrane.

This Detail featured these Firestone Products:

Product

- Firestone Geotextile

Item #

Varies by Size