

Firestone EPDM Geomembrane Installation Detail 6

Unrolling Firestone EPDM Geomembrane (Downslope)



Step 1- Starting at the apex of the slope; unroll the Firestone EPDM Geomembrane in the direction shown on the outer wrapper.



Step 2- Use scissors to trim the membrane to fit.

Note: Do not use a knife.

This Detail featured these Firestone Products:

Product

- Firestone EPDM Geomembrane

Item #

Varies by Size