

Firestone EPDM Geomembrane Installation Detail 11

Priming Cover Strip Tape for Continuation to the Next Roll



Step 1- Ensure the liner is dry and free of mud and other contaminants.



Step 2- Prime the final 2.00" to 4.00" (5.08 to 10.16 cm) of Cover Strip Tape and overlap the second roll of this tape to the edge of the primed area.



Step 3- Roll the tapes to mate them together.

Note: A similar methodology can be used when continuing on with 3.0" (7.62 cm) Splice Tape



Firestone EPDM Geomembrane Installation Detail 11 (Con't)
Priming Cover Strip Tape for Continuation to the Next Roll

This Detail featured these Firestone Products:

Product

- Firestone EPDM Geomembrane
- 6" (15.24 cm) QuickSeam™ Cover Strip
- QuickPrime™ Plus Primer
- QuickScrubber™
- Hand Roller

Item #

- Varies By Size
W56RAC1693
or
W56RAC1616
or
W563587041
W563587044
W563582045
W563582023