

## Firestone EPDM Geomembrane Installation Detail 13

### **Removing an Air Bubble from a Taped Seam**



**Step 1**- Attempt to hand roll the bubble to the edge of the 6.00" (15.24 cm) QuickSeam™ Cover Strip.



**Step 2**- If unable to roll the bubble out, lance it.



**Step 3**- Using standard seaming procedures; cover the lanced hole with a patch of QuickSeam Cover Strip.

**Notes:**

1. You must extend patch a minimum of 3.00" (7.62 cm) beyond any cuts.
2. Caulk if necessary.

**Note:** Similar procedures can be used on 3.00" (7.62 cm) Splice Tape



---

## Firestone EPDM Geomembrane Installation Detail 13 (Con't)

### **Removing an Air Bubble from a Taped Seam**

#### **This Detail featured these Firestone Products:**

##### **Product**

- Firestone EPDM Geomembrane
- 6" (15.24 cm) QuickSeam Cover Strip
- QuickPrime™ Plus Primer
- QuickScrubber™
- Hand Roller

##### **Item #**

Varies By Size  
W56RAC1616  
or  
W56RAC1693  
or  
W563587041  
W563587044  
W563582045  
W563582023