

# Firestone

## SPECIALTY PRODUCTS

---

### Firestone EPDM Geomembrane Installation Detail 19

### **Installing Firestone EPDM Geomembrane to a Corner Wall**



**Step 1-** Ensure the liner is dry and free of mud or other contaminants.



**Step 2-** To solidify the Firestone EPDM Geomembrane corner seam, apply QuickPrime™ Plus Primer along each wall.



**Step 3-** Test the primer flash-off by touching the primed area with your finger and pushing forward at an angle. The primer should not string as your finger is moved up and away.



**Step 4-** Adhere the 3.00" (7.62 cm) QuickSeam™ Splice Tape to the primed surface of the bottom panel.

# Firestone

## SPECIALTY PRODUCTS

---

### Firestone EPDM Geomembrane Installation Detail 19 (Con't)

#### **Installing Firestone EPDM Geomembrane to a Corner Wall**



**Step 5-** Remove the release paper and adhere the Firestone EPDM Geomembrane flap to this Splice Tape to create a sealed seam.



**Step 6-** Using a hand roller; roll the seam to ensure adhesion at all points.

**Note:** See detail 21- "Installing an Inside QuickSeam Corner Flashing" for proper installation of an inside corner.

#### **This Detail featured these Firestone Products:**

##### **Product**

- Firestone EPDM Geomembrane
- QuickPrime Plus Primer
- QuickScrubber™
- Hand Roller

##### **Item #**

Varies By Size  
W563587041  
or  
W563587044  
W563582045  
W563582023