



- NOTES:
1. REFER TO FIRESTONE WEBSITE FOR MOST CURRENT INFORMATION.
  2. INSTALL FIRESTONE TERMINATION BAR WITH 1/4" (6 mm) GAP BETWEEN ADJOINING SECTIONS.
  3. TERMINATION BAR MUST BE CUT AT INSIDE AND OUTSIDE CORNERS. **DO NOT BEND AROUND CORNERS.**
  4. TERMINATION BAR MUST BE FASTENED WITHIN 1" (25 mm) MAX. OF ALL SECTION ENDS.
  5. APPLY WATERBLOCK IN A 3/8" (10 mm) TO 1/2" (13 mm) BEAD AT APPROXIMATELY 10 LF PER TUBE.

**MASONRY AND CONCRETE  
WALLS / CURBS MUST BE  
WATERPROOFED AND  
MAINTAINED IN ORDER  
FOR ANY SURFACE  
MOUNTED TERMINATION  
TO BE EFFECTIVE.**

MAXIMUM WARRANTY: **20 YEARS**