



NOTES:  
 1. REFER TO FIRESTONE WEBSITE FOR THE MOST CURRENT INFORMATION.

2. REFER TO B-12 FOR CROSS SECTION OF FLASHING AND CURB ATTACHMENT.
3. APPLY LAP SEALANT AT 9" QUICKSEAM FORMFLASH AS INDICATED. REFER TO LS-9 FOR SEAM EDGE TREATMENT.
4. REFER TO SA C-2a & SA C-2b FOR DETAILED INSTALLATION INFORMATION.
5. USE APPROPRIATE FIRESTONE PRIMER TO CLEAN AND PRIME EPDM MATING SURFACES PRIOR TO INSTALLATION OF QUICKSEAM PRODUCTS.

MAXIMUM WARRANTY: **20 YEARS**

**OUTSIDE CORNER AT WELDED WATERTIGHT CURB  
 (FLANGES UNDER 2")**

RUBBERGARD™ EPDM SA

ACCEPTABLE SYSTEMS: EPDM SA

ISSUE / REVISION DATE:	DETAIL NO.
8/15/2015	EPDM SA C-2
NOT TO SCALE	