



NOTES:

1. REFER TO FIRESTONE WEBSITE FOR MOST CURRENT INFORMATION.
2. NAILING AND METAL COUNTERFLASHING ARE NOT REQUIRED IF MEMBRANE IS RUN UP AND OVER CURB WALLS PRIOR TO INSTALLATION OF R.T.U.
3. BONDING ADHESIVE REQUIRED BETWEEN MEMBRANE AND INSULATION FOR FULLY ADHERED SYSTEMS.
4. WHEN REINFORCEMENT OF TPO MEMBRANE IS EXPOSED, REFER TO UT-LS-14 FOR CUT EDGE EXPOSED, REFER TO UT-LS-14 FOR CUT EDGE
5. INSTALL METAL WORK IN ACCORDANCE WITH CURRENT SMACNA RECOMMENDATIONS.
6. WOOD BLOCKING CAN BE USED BELOW CURB FLANGE (TO MATCH INSULATION THICKNESS) CAN BE SUBSTITUTED FOR STRUCTURAL CURB ATTACHMENT
7. APPROVED WOODEN CURBS CAN BE USED IN PLACE OF METAL CURBS
8. REFER TO STANDARD FIRESTONE DETAILS FOR CORNER FLASHING

BONDING ADHESIVE (SEE NOTES)

Firestone
Firestone Building Products

**FLASHING DETAIL AT INSULATED CURB W/QUICKSEAM RPF - W/COUNTERFLASHING
(UNIT FLANGE MOUNTED TO SUBSTRATE)**

SUNWAVE™ PRISMATIC SKYLIGHTS ACCEPTABLE SYSTEMS: TPO/EPDM

MAXIMUM WARRANTY: **20 YEARS**

ISSUE / REVISION
DATE:
11/02/2017

DETAIL NO.
FS-DL-9