

RubberGard™ EPDM SA

Item Description

.060" x 5' x 100'
.060" x 10' x 100'

Item Number

W56L60510SA
W56L61010SA



Product Information

Description:

Firestone RubberGard EPDM SA membrane with Secure Bond™ Technology is designed to be the next generation of self adhered roof system application. Secure Bond Technology is factory applied which helps ensure uniform adhesion across the entire membrane, creating a powerful bond with the substrate. This advanced technology not only improves installation speed over traditional fully adhered applications, but also widens the installation window with the ability to be installed down to 20 °F (-7 °C). With no VOCs, RubberGard EPDM SA with Secure Bond Technology is an excellent solution for all your fully adhered roofing needs.

RubberGard EPDM SA membrane meets or exceeds all the requirements for ASTM D 4637 for Type I non-reinforced EPDM single-ply roofing membranes.

Membrane Preparation:

1. Substrates must be clean, dry and free of foreign material such as grease and any debris which could inhibit adhesion. This may require cleaning with a broom or blower.
2. Insulation must be fastened per current Firestone technical specifications to provide a proper substrate.
3. Install RubberGard EPDM SA membrane only when ambient and substrate temperatures are minimum 20 °F (-7 °C) and rising. Do not install RubberGard EPDM SA below this minimum temperature.
4. Unroll and position the membrane over the substrate to achieve the desired alignment and overlaps. For an even better alignment and adhesion, allow membrane to relax 30 minutes before positioning and adhering.
NOTE: Once membrane has relaxed, follow field membrane and roof edge membrane application methods below to attach the membrane to the approved substrate.

Method of Application:

Field Membrane Application (Steps 1-5):

1. Once the membrane has relaxed in place a minimum of 30 minutes (longer in colder weather), and the seam positions are aligned, carefully fold back the leading edge of the membrane at one end to expose the release liner without disturbing the original position of the membrane.
2. Starting from the center split of the exposed release liner, remove the liner on both sides of the split at a 45° angle back beyond the membrane edge, making sure to have pulled enough of the release liner to hold below the membrane. Remove approximately 5' (minimum) of release liner from one end of the sheet and adhere it to the substrate. The release liner removed should be enough to extend out beyond the edges of the membrane. **NOTE: Do not fold the length of the roll in half.**
3. Keeping the membrane flat and secured, and seam overlap aligned, continue removing the release liner at a 45° angle along the length of the entire sheet (up to 100'). Pulling the release liner at a higher angle can cause the sheet to move and may trap air. The two halves of the release liner should be pulled out at the same time by two people. Keep the release liner as close to the roof surface as possible during removal. **NOTE: Removal of the liner and any handling of the exposed SA adhesive should be done by two people minimum.**

RubberGard™ EPDM SA

Field Membrane Application (Steps 1-5) Continued:

4. To initiate adhesion, use a stiff bristled broom and apply downward pressure to broom in the installed membrane. Broom the installed membrane across the width of the sheet working toward the roof edge. Repeat the process for the other half of the membrane by starting from the center and broom towards the field side of the roof.
5. Roll the installed membrane with a weighted roller (5 lb per lineal inch) across the width of the membrane sheet to ensure full contact with the substrate. **NOTE: Do not roll membrane in place with a weighted roller if installed over ISOGARD HD or RESISTA.**

Roof Edge (Gravel Stop, Gutter Edge) Membrane Application (Steps 1-6):

1. Align the membrane's position along the roof edge and allow the membrane to relax in place a minimum of 30 minutes (longer in colder weather).
2. To prepare the membrane for installation at the roof edge, carefully fold one end of the membrane sheet back approximately 10' (minimum). Fold the membrane from one end and do not fold along the length of the roll.
3. Starting with the outside (roof edge) liner, carefully pull it underneath the membrane, back towards the field of the roof at a 45° angle to expose the SA adhesive without disturbing the original position of the membrane. Next, pull the inside liner, making sure to maintain a 12" wide (minimum) separation between the two liner halves. Back-roll the exposed SA section (minimum 10') onto the prepared substrate and set in place without trapping any air or allowing wrinkles beneath the sheet. **NOTE: Removal of the liner and any handling of the exposed SA adhesive should be done by two people minimum.**
4. Keeping the release liner as close to the roof surface as possible and maintaining a 10' (minimum) space between the two liner halves, pull both the leading outside (roof edge) liner and then the following inside (field) liner sections at a 45° angle along the length of the roof edge. Pulling the release liner at a higher angle can cause the sheet to move and may trap air.
5. To initiate adhesion, use a stiff bristled broom and apply downward pressure to broom in the installed membrane. Broom the installed membrane across the width of the sheet working toward the roof edge. Repeat the process for the other half of the membrane by starting from the center and broom towards the field side of the roof.
6. Roll the installed membrane with a weighted roller (5 lb per lineal inch) across the width of the membrane sheet to ensure full contact with the substrate. **NOTE: Do not roll membrane in place with a weighted roller if installed over ISOGARD HD or RESISTA.**

Seaming:

NOTE: It is very important that both surfaces are clean and no moisture is present on the splicing surfaces.

Fold back the top portion of the field seam exposing the bottom surface of the field seam. Prime the seam area to receive QuickSeam™ 3" seam tape with a QuickPrime™ product per current Firestone QuickSeam 3" Seam Tape installation instructions. Use the touch/push test to verify the primer is flashed off. When the primer is ready, apply the QuickSeam 3" seam tape per current Firestone QuickSeam 3" Seam Tape installation instructions.

Storage:

- Warehouse membrane in a clean dry location.
- Membrane stored on jobsite must be kept dry.
- Material must be a minimum of 20 °F (-7 °C) prior to installation.
- Store away from sources of punctures and physical damage.
- Make certain the structural decking will support the loads incurred by material when stored on rooftop. The deck load limitations should be specified by the project designer.
- Store away from ignition sources.

RubberGard™ EPDM SA

Shelf Life:

18 Months when stored between 60 °F (16 °C) and 80 °F (27 °C) out of direct sunlight.

Precautions:

- Take care when moving, transporting and handling to avoid sources of punctures and physical damage.
- Removal of the plastic release liner from the adhesive backing may create a static electric charge; care should be used when removing and handling the release liner.
- Refer to Safety Data Sheets (SDS) for additional safety information.

Typical Properties- Secure Bond Pressure Sensitive Adhesives:

| Property | Test Method | Units | Performance Min. | Typical Values |
|-------------------|---------------|---|------------------|----------------|
| Color | --- | --- | --- | Clear |
| Nominal Thickness | ASTM E 408-71 | in (mm) | N/A | 0.007 (0.180) |
| Weight | --- | lb/ft ² (kg/m ²) | --- | 0.040 (0.002) |

Typical Properties

| Property | Test Method | Units | Performance Minimum | Typical Performance 60 mil |
|-----------------------------|---------------------------|--|---------------------------|----------------------------|
| Overall Thickness | D 412 | in (mm) | 0.0504 (1.372) | 0.059 (1.499) |
| Tensile Strength | D 412 (Die C) | Psi (MPa) | 1305 (9.0) | 1454 (10.0) |
| Elongation, Ultimate | D 412 (Die C) | % | 300 | 622 |
| Tensile Set | D 412, Method A (Die C) | % | 10 | 2.18 |
| Tear Resistance | D 624 (Die C) | lbf/in (kN/m) | 159 (26.3) | 219 (38.4) |
| Brittleness Point | D 2137 | °F (°C) | -49 (-45) | -49 (-45) |
| Ozone Resistance, no cracks | D 1149 | --- | --- | Pass |
| Heat Aging: | D 573 | | | |
| Tensile Strength | D 412 (Die C) | Psi (MPa) | 1205 (8.3) | 1490 (10.3) |
| Elongation, Ultimate | D 412 | % | 200 | 322 |
| Tear Resistance | D 624 | lbf/in (kN/m) | 125 (21.9) | 179 (31.3) |
| Linear Dimensional Change | D 1204 | % | ± 1.0 | -0.32 |
| Water Absorption | D 471 | % | +8, -2 | +1.51 |
| Weight | --- | lb/sqft | --- | .47 lb/sqft |
| Factory Seam Strength | D 816 Method B (Modified) | lbf/in (kN/m) | 50 (8.8) or Sheet Failure | Sheet Failure |
| Weather Resistance: | | | | |
| Visual Inspection | D 518 | --- | Pass | Pass |
| PRFSE | D 518 | % | 30 | 53 |
| Elongation, Ultimate | D 412 (Die C) | % | 200 | 255 |
| Air Permeance (Material) | E 2178* | ft ³ /ft ² (L/(s·m ²)) | <0.004 (0.02) | Pass |

*The ASTM 2178 values listed are for the air permeance of the RubberGard EPDM SA membrane component only. For use of the product as a component in an air barrier assembly, please consult your Firestone Building Systems Advisor (BSA), Code Agency or Authority having Jurisdiction (AHJ) for the acceptable air barrier assembly details.

RubberGard™ EPDM SA

Substrates

| Acceptable Substrates | Primer Req'd | Acceptable Application Temperatures | Special Application Considerations / Notes |
|---------------------------------|--------------|-------------------------------------|---|
| Poly ISO 95+ G/L | No | 20 - 120 °F (-7 – 49 °C) | |
| ISOGARD™ HD | No | 20 - 120 °F (-7 – 49 °C) | Do not roll in place with weighted roller |
| RESISTA™ | No | 20 - 120 °F (-7 – 49 °C) | Do not roll in place with weighted roller |
| Poured in Place or plank Gypsum | No | 20 - 120 °F (-7 – 49 °C) | |
| Structural Concrete | No | 20 - 120 °F (-7 – 49 °C) | Must be clean, dry and properly cured prior to application |
| Lightweight Concrete | No | 20 - 120 °F (-7 – 49 °C) | Use on clean, dry and properly cured cellular lightweight concrete only, not acceptable with lightweight aggregate concrete |
| DensDeck* | No | 20 - 120 °F (-7 – 49 °C) | |
| DensDeck Prime | No | 20 - 120 °F (-7 – 49 °C) | |
| Securock** | No | 20 - 120 °F (-7 – 49 °C) | |
| Plywood | No | 20 - 120 °F (-7 – 49 °C) | Check local code for acceptance of direct application |
| OSB Board | No | 20 - 120 °F (-7 – 49 °C) | Check local code for acceptance of direct application |
| CMU/Masonry Block | No | 20 - 120 °F (-7 – 49 °C) | Must be clean & dry prior to application. Firestone recommends testing a small area for application to determine if a primer is required. |

*DensDeck is a registered trademark of the G-P Gypsum Corporation

**Securock is a registered trademark of the USG Corporation

LEED® Information:

Post Consumer Recycled Content: 0%
 Post Industrial Recycled Content: 3-5%
 Manufacturing Location: Tuscumbia, AL

NOTE: LEED® is a registered trademark of the U.S. Green Building Council.



Please contact Quality Building Services Technical Department at 1-800-428-4511 for further information.

This sheet is meant to highlight Firestone products and specifications and is subject to change without notice. Firestone takes responsibility for furnishing quality materials which meet published Firestone product specifications. Neither Firestone nor its representatives practice architecture. Firestone offers no opinion on and expressly disclaims any responsibility for the soundness of any structure. Firestone accepts no liability for structural failure or resultant damages. Consult a competent structural engineer prior to installation if the structural soundness or structural ability to properly support a planned installation is in question. No Firestone representative is authorized to vary this disclaimer.